TITLE: Reactor Startup Procedure	Minor Rev: 001
ALITHOD: Caratab Cadar 027 (diagond)	

1.0 *MODE* 3

- 1.1 **VERIFY** Mode Switch in SHTDN Position
- 1.2 **VERIFY** Reactor Scram Reset
- 1.3 **VERIFY** Both RRC Pumps running at 25% rated flow
- 1.3 **PLACE** the Mode Switch in STRT Position

2.0 *MODE 2*

2.1 **VERIFY** RWM Bypass Off

2.2 POWER

- 2.2.1 **SELECT** the first control rod as directed by the RWM
- 2.2.2 WITHDRAW the selected control rod
- 2.2.3 **CONTINUE** withdrawing control rods to reach criticality
- 2.2.4 MAINTAIN Reactor Period GT 30 secs
- 2.2.5 **WITHDRAW** SRMs to maintain indication levels between the rod blocks (100 cps and 1x10e5 cps)
- 2.2.6 **ADVANCE** the IRM range change switches to maintain an indication of 25 to 75

3.0 HEATING RANGE

3.1 POWER

3.1.1 **VERIFY** APRM response as IRM range increases

TITLE: Reactor Startup Procedure Major Rev: 001	
---	--

AUTHOR: ScratchCoder027 (discord) Minor Rev: 001

Page: 2/2

3.1.2 **VERIFY** LRPM response with APRM

3.2 <u>WHEN</u> Reactor Power GE 5% <u>THEN</u> **PLACE** the Reactor Mode Switch in the RUN Position

4.0 *MODE 1*

- 4.1 POWER
- 4.1.1 **CONTINUE** increasing power to 100% APRM

Table 1.1, Used Acronyms

"GE"	Greater Than or Equal To
"LE"	Less Than or Equal To
"GT"	Greater Than
"LT"	Less Than